

TERRON 9



Hi LDV APP – GETTING STARTED GUIDE




**BRING
IT ON.**

Hi LDV CONNECTED APP – CONNECTING YOUR VEHICLE


STEP ONE

1. Download the Hi LDV app for your mobile device from the Apple app store or Google Play store.





STEP TWO



2. Create a new account or if you've already registered, log in with your existing details.




STEP THREE

- The app will need to scan your vehicle's Account Login QR code, which can be found by selecting the 'Inbox' app in your infotainment display.

You can find the 'Inbox' app by navigating to  Applications, then selecting  Inbox.





On your device, select '**Bind My Vehicle**' in the app to scan the Account Login QR code now shown on your vehicle's display.



STEP FOUR


- Once completed, a summary of your vehicle details should now appear under 'Account'.



Select  **Connect Vehicle** to continue.

STEP FIVE


- Scan the 'Bind the Vehicle' QR code on your vehicle's display using 'Bind the Vehicle' in the app to complete the connection.



Note: After binding your vehicle using the QR code, it may take up to 24 hours to activate. You will be asked to enter a four digit security code that will be used for remote control features on your app.

STEP SIX


- Your vehicle is now successfully connected to your app when your vehicle is shown on the home screen.



Hi LDV CONNECTED APP – DISCONNECTING YOUR VEHICLE


STEP ONE

1. To disconnect your vehicle from the Hi LDV app, tap your vehicle name in the top left corner from the home screen.




STEP TWO

2. Under 'Vehicle Management', select the vehicle you wish to disconnect.




STEP THREE

3. Select '**Unbind**' to disconnect your vehicle. You will receive a code to the email address linked to this account which will need to be entered to successfully disconnect your vehicle.



STEP FOUR

4. Once entered and confirmed, the vehicle is now **disconnected** from the Hi LDV app.



Disclaimers: LDV Connected App requires an active, compatible device with mobile data, internet access and the app installed. The user is responsible for internet access and mobile network data charges required for the LDV Connected App. Features and app are subject to change without notice at anytime. LDV Connected Services Standard are complimentary for 5 years from vehicle delivery including vehicle app connectivity and vehicle status check. Charges may apply thereafter. LDV Connected Services require mobile data, network reception and a GPS signal in order to operate. Will not be available in areas that are not covered by Optus 4G network in Australia or if services are terminated or disabled. Features are subject to change.

NEED HELP?
VISIT [LDVAUTOMOTIVE.COM.AU/CONNECTED-APP](https://ldvautomotive.com.au/connected-app)
OR CALL 1800 716 894

